

Alphabetical index

Alphabetical index

A	A/C (Air conditioning system)	166
	ABS (Anti-lock brake system)	144
	AFS (Adaptive front lighting system)	119
	Adaptive front lighting system (AFS)	119
	Air conditioning filter	295
	Air conditioning system (A/C)	
	Air conditioning filter	295
	Automatic air conditioning system	166
	Airbags	
	Airbag operating conditions	63
	Airbag precautions for your child	67
	Airbag warning light	334
	Curtain shield airbag operating conditions	63
	Curtain shield airbag precautions	67
	General airbag precautions	67
	Locations of airbags	61
	Modification and disposal of airbags	71
	Proper driving posture	59, 67
	Side airbag operating conditions	63
	Side airbag precautions	67
	SRS airbags	61
	Alarm	56
	Antenna	183
	Anti-lock brake system (ABS)	144
	Armrest	230
	Ashtrays	223
	Audio system	
	Antenna	183
	AUX adapter	204

	CD player/changer	186
	MP3/WMA disc	193
	Optimal use	201
	Radio	178
	Steering wheel audio switch	205
	Automatic air conditioning system	166
	Automatic headlight leveling system	120
	Automatic light control system	118
	Automatic transmission	
	Automatic transmission	97
	If the shift lever cannot be shifted from P	361
	S mode	99
	AUX adapter	204
B	BA (Brake assist)	144
	Back-up lights	
	Wattage	388
	Battery	
	Checking	275
	If the vehicle has discharged battery	366
	Preparing and checking before winter	156
	Bottle holders	215
	Brake	
	Fluid	274
	Parking brake	104
	Brake assist (BA)	144

C	Care	
	Exterior	248
	Interior	250
	Seat belts	251

Cargo capacity	152
Cargo hooks	236
CD changer	186
CD player	186
Chains	156
Child restraint system (CRS)	
Booster seats, definition	72
Booster seats, installation	76
Convertible seats, definition	72
Convertible seats, installation	76
Infant seats, definition	72
Infant seats, installation	76
Installing CRS with lower anchorage	79
Installing CRS with seatbelts	76
Installing CRS with top straps	80
Child safety	
Airbag precautions	67
Battery precautions	277, 368
Child restraint system	72
Child-protectors	20
How your child should wear the seatbelt	37
Installing child restraints	75
Moon roof precautions	50
Power window lock switch	45
Power window precautions	47
Removed electronic key battery precautions	298
Seat belt comfort guide	35
Seat belt extender precautions	39
Seat belt precautions	38
Seat heater precautions	227, 229
Trunk precautions	25
Child-protectors	20
Cigarette lighter	224

Cleaning	
Exterior	248
Interior	250
Seat belts	251
Clock	219
Coat hooks	234
Compass	244
Condenser	274
Console box	212
Cooling system	
Engine overheating	369
Cornering assist sensors	138
Cruise control	
Cruise control	126
Dynamic radar cruise control	129
Cup holder	214
Curtain shield airbags	61
Customizable features	400

D

Daytime running light system	119
Defogger	
Rear window	174
Side mirror	174
Dimension	374
Dinghy towing	162, 163
Display	
Dynamic radar cruise control	129
Satellite switch mode	220
Trip information	115
Warning message	338
Do-it-yourself maintenance	259
Door courtesy lights	
Door courtesy lights	207
Wattage	388
Door pockets	215

Doors	
Door glasses	45
Door lock	19
Side mirrors	43
Driver's seat belt reminder light	335
Driving	
Correct posture	59
Procedures	86
Driving position memory	28
E	
Electric power steering (EPS)	144
Electronic key	
If your electronic key battery is discharged	363
Emergency, in case of	
If the engine will not start	360
If the shift lever cannot be shifted from P	361
If the vehicle has discharged battery	366
If the warning buzzer sounds	333
If the warning light turns on	333
If the warning message is displayed	338
If you have a flat tire	352
If you lose your keys	362
If you think something is wrong	329
If your electronic key battery is discharged	363
If your vehicle becomes stuck	371
If your vehicle needs to be towed	322
If your vehicle overheats	369
Engine	
Compartment	265

Engine switch	94
Hood	262
How to start the engine	94
Identification number	375
If the engine will not start	360
Overheating	369
Engine compartment cover	267
Engine coolant	
Capacity	379
Checking	272
Preparing and checking before winter	156
Engine coolant temperature gauge	105
Engine immobilizer system	54
Engine oil	
Capacity	378
Checking	268
Preparing and checking before winter	156
Engine oil maintenance data	271
EPS (Electric power steering)	144
Event data recorder	331

F	
First-aid kit storage belt	236
Floor mat	235
Fluid	
Brake	274
Washer	278
Fog lights	
Switch	121
Wattage	388
Foot well lighting	207
Front fog lights	
Switch	121
Wattage	388

Front passenger's seat belt	
reminder light.....	335
Front seats	
Adjustment	26
Driving position memory	28
Seat position memory.....	31
Front turn signal lights	
Wattage	388
Fuel	
Capacity.....	377
Fuel gauge.....	105
Fuel pump shut off system	330
Gas station information	419
Information.....	389
Refueling	51
Fuel filler door.....	51
Fuel pump shut off system	330
Fuses.....	299

G	Garage door opener.....	239
	Gas station information.....	419
	Gauges.....	105
	Glove box	211
	Glove box light.....	212

H	Head restraints	
	Adjusting	33
	Headlight aim	313
	Headlight cleaner	125
	Headlights	
	Discharge headlights	
	precautions	320
	Replacing light bulbs	314
	Switch.....	118
	Wattage	388

Heaters	
Seat heaters	226, 228
Side mirror.....	174
Hill-start assist control	144
Hood.....	262
Hooks	
Cargo	236
Coat.....	234
Shopping bag	236

I	I/M test.....	258
	Identification	
	Engine.....	375
	Vehicle	375
	Illuminated entry system	208
	Indicator lights.....	111
	Initialization	
	Items to initialize	404
	Inside rear view mirror	42
	Interior lights	
	Interior lights.....	207
	Switch.....	209
	Wattage.....	388

J	Jack	
	Positioning the jack	263
	Replacing the wheel	352
	Jack handle.....	352

K	Keys	
	Electronic key	2
	Engine switch.....	94
	If you lose your keys.....	362
	If your electronic key battery	
	is discharged.....	363
	Key number	2

Keys	2
Mechanical key	2
Wireless remote control	16

L

Light bulbs

Replacing	314
Wattage	388

Lights

Door courtesy lights	207
Fog light switch	121
Headlights switch	118
Interior light switch	209
Outer foot lights	207
Overhead courtesy light	207
Personal light switch	209
Replacing light bulbs	314
Scuff lighting	207
Shift lever lighting	207
Turn signal lever	103
Vanity lights	218
Wattage	388
Load capacity	155

M

Maintenance

Do-it-yourself maintenance	259
General maintenance	255
Maintenance data	374
Maintenance requirements	253

Manual transmission

Meter

Instrument panel light control	106
Meters	105

Mirrors

Inside rear view mirror	42
Side mirror heater	174
Side mirrors	43

Vanity mirrors	218
Moon roof	48
MP3 disc	193
Multi-information display	114

O

Odometer

Oil

Engine oil	268
------------------	-----

Opener

Fuel filler door	51
Hood	262
Trunk	23

Outer foot lights

Outer foot lights	207
Wattage	388

Outside rear view mirrors

Adjusting and folding	43
Driving position memory	28

Outside temperature display

Overhead console

Overhead courtesy lights

Overhead courtesy lights	207
Wattage	388

Overheating, Engine

P

Parking assist sensors

Parking brake

Parking lights

Replacing light bulbs	314
Switch	118
Wattage	388

PCS (Pre-collision system)

Personal lights

Switch	209
--------------	-----

Micro dust and pollen removal

mode	170
------------	-----

Power outlet.....	225
Power windows.....	45
Pre-collision system (PCS).....	149

R

Radar cruise control	129
Radiator.....	274
Radio	178
RDS (Radio data system).....	179
Rear sunshade.....	231
Rear turn signal lights	
Replacing light bulbs	314
Wattage	388
Rear view mirror	
Compass	244
Rear window defogger.....	174
Replacing	
Electronic key battery	297
Fuses	299
Light bulbs	314
Reporting safety defects for	
U.S.A. owners	406

S

Scuff lighting.....	207
Seat belts	
Adjusting the seat belt	35
Automatic Locking Retractor	
(ALR).....	36
Child restraint system	
installation	75
Cleaning and maintaining	
the seat belts.....	251
Emergency Locking Retractor	
(ELR).....	36
How to wear your seat belt.....	34
How your child should wear	
the seat belt.....	37

Pregnant women,	
proper seat belt use	36
Reminder light	335
Seat belt extenders	37
Seat belt pretensioners	35
Seat heaters	226, 228
Seat position memory	31
Seat ventilators	228
Seating capacity	155
Seats	
Child seats/child restraint	
system installation.....	75
Cleaning	250
Driving position memory	28
Front passenger seat position	
memory	31
Head restraint.....	33
Properly sitting in the seat	59
Seat adjustment	26
Seat adjustment precautions.....	27
Seat heaters	226, 228
Ventilated seats	228
Service reminder indicators	111
Shift lever	
Automatic transmission	97
If the shift lever cannot be	
shifted from P	361
Manual transmission	101
Shift lever lighting	207
Shift lock system.....	361
Shopping bag hooks.....	236
Side airbags.....	61
Side marker lights	
Switch.....	118
Side mirror	
Adjusting and folding.....	43
Driving position memory	28

Smart access system with push-button start	
Entry function.....	4
Starting the engine.....	94
Spare tire	
Inflation pressure.....	289
Spare tire.....	352
Spark plug.....	379
Specifications	374
Speedometer	
Speed indicator	105
Speedometer	105
Steering wheel	
Audio switches	205
Driving position memory.....	28
Manual adjustment	40
Power adjustment	41
Storage feature.....	211
Stuck	
If your vehicle becomes stuck.....	371
Sun visors	217
Sunshade	
Rear	231
Roof	49
Switch	
ECT switch	98
Engine switch.....	94
ETCS switch.....	101
Fog light switch.....	121
Light switches.....	118
Power door lock switch.....	19
Power window switch.....	45
Satellite switches	220
Transmission shift switches.....	99
Window lock switch	45
Wipers and washer switch.....	122

T Tachometer	
Tacho indicator	105
Tachometer	105
Tail lights	
Switch.....	118
Theft deterrent system	
Alarm.....	56
Engine immobilizer system.....	54
Theft prevention labels.....	58
Tire inflation pressure	289
Tire information	
Glossary	397
Size.....	394
Tire identification number.....	393
Uniform tire quality grading.....	395
Tires	
Chains.....	156
Checking.....	279
If you have a flat tire	352
Inflation pressure	289
Inflation pressure sensor	280
Information	392
Replacing	352
Rotating tires.....	279
Size.....	383
Snow tires.....	156
Tools.....	352
Total load capacity	155
Towing	
Dinghy towing	162, 163
Emergency towing.....	322
Trailer towing	161
TRAC (Traction control).....	144
Traction control (TRAC).....	144
Transmission shift switches.....	99
Trip meter	105

Trunk	
Extending a space	233
Opener.....	23
Trunk light	
Trunk light	24
Wattage	388
Turn signal lights	
Replacing light bulbs	314
Switch.....	103
Wattage	388

V

Vanity lights	
Vanity lights.....	218
Wattage	388
Vanity mirrors	218
VDIM (Vehicle dynamics integrated management).....	144
Vehicle dynamics integrated management (VDIM)	144
Vehicle identification number	375
Vehicle stability control (VSC)	144
Ventilators.....	228
VSC (Vehicle stability control)	144

W

Warning buzzers	
Brake system	333
Open door	335
Seat belt reminder	334
Warning lights	
Anti-lock brake system (ABS) ...	334
Brake assist system	334
Brake system	333
Charging system	334
Electric power steering warning light.....	334

Electronic engine control system	334
Low fuel level	335
Low tire pressure warning light	335
Master warning light.....	335
Open door.....	335
Pre-collision system.....	334
Pretensioners	334
Seat belt reminder light.....	335
SRS airbags.....	334

Warning messages

AWD system	339
Dynamic radar cruise control.....	339, 343
Engine oil level	343
Engine oil maintenance	343
Engine oil pressure	338
Hill-start assist control	342
Hood.....	343
Lexus parking assist sensor.....	339, 343
Moon roof	343
Open door.....	343
Parking brake	343
Pre-collision system.....	339, 343
Smart access system with push-button start.....	349
Steering lock.....	339
Tire inflation pressure warning system.....	339, 343
Traction control (TRC)	342
Trunk	343
Vehicle stability control (VSC).....	342
Washer fluid	343

Washer

- Checking278
- Preparing and checking
 - before winter 156
- Switch122

Washing and waxing.....248

Weight

- Cargo capacity.....152
- Load limits 155
- Weight374

Wheels293

Window glasses45

Window lock switch45

Windows

- Power windows..... 45
- Rear window defogger174
- Washer122

Windshield wipers122

Wireless remote control

- Replacing the battery297

WMA disc 193